



- NOTES:
1. ALL WIRE CONNECTION SHALL BE MADE WITH APPROVED CONNECTORS.
 2. MAKE ALL WIRE SPICES IN VALVE BOXES.
 3. LEAVE A MINIMUM OF 12" EXTRA WIRE AT ALL SPICE POINTS.
 4. TEST EARTH TO GROUND RESISTANCE AT ALL GROUND POINTS.
 5. EARTH TO GROUND RESISTANCE MUST BE LESS THAN 50 OHMS.

